

# Pedal Cover Installation Instructions



# Pedal Cover Installation Instructions

**Building American Quality... With A Lifetime Warranty!®**

TOLL FREE 1-877-469-7440 • tech@lokar.com • www.lokar.com

### General Installation Notes:

Please read these instructions completely before beginning the installation. If you have any questions, please call.

Before beginning the installation, disconnect the negative battery cable and use wheel chocks to block the vehicle's wheels.

Make sure the engine, transmission, body and frame are properly grounded. We recommend using anti-seize lubricant on all aluminum threads.




Fig. 1

All product installation instructions can be found by visiting [www.lokar.com/instructions.html](http://www.lokar.com/instructions.html).

Refer to Figs. 1, 2, and 3 for the component names.

### Brake or Clutch Pedal Covers

**Step 1:** Remove any existing pedal pads (if applicable).

**Step 2:** Position the new cover on the existing brake or clutch pedal, with the wider side at the top. Install a #8-32 x 3/4" socket head bolt in each of the upper holes of the cover, and a #8-32 x 5/8" bolt into each of the lower holes.

**Step 3, Automatic Transmission Brake Pedal (Fig. 1):** Place one of the Auto Backing Plates on each side of the back of the pedal, with the #8-32 socket head bolts protruding through the back side of the backing plates. Secure the backing plates with the #8-32 nylock nuts.




Fig. 2

### Brake or Clutch Pedal Covers, continued:

**Step 3, Manual Transmission Brake and Clutch Pedals (Fig. 2):**

Place the long backing plate at the top on the back side of the pedal, with the #8-32 socket head bolts protruding through the back side of the backing plate. Secure the long backing plate loosely with two nylock nuts.

Then, place the short backing plate at the bottom on the back side of the pedal, with the bolts protruding through the back side of the backing plate. Secure the short backing plate with two nylock nuts. Tighten all four nuts using a 9/64" Allen wrench and an 11/32" wrench or socket. **Fig. 3**

### Emergency Brake Pedal Cover (Fig. 4)

**Step 1:** Remove any existing pedal pads (if applicable).

**Step 2:** Position the new cover on the emergency brake pedal. Mark and center-punch the location of the two bolt holes in the cover onto the pedal.

### Emergency Brake Pedal Cover, continued

**Step 3:** Drill a 7/32" diameter hole in the emergency brake pedal at each of your marks.

**Step 4:** Install the cover onto the emergency brake pedal, using the #10-24 x 5/8" flat head bolts and nylock nuts. Tighten using a 1/8" Allen wrench and a 3/8" wrench or socket.

**Step 5:** Peel the paper backing off of the back side of the rubber pad to reveal the adhesive. Place the rubber pad into the recess in the front side of the cover, and press firmly into place.




Fig. 3




Fig. 4